

Installation Guide

OPOS Driver

Ver. 1.01

AP3

Introduction

This is a manual for AP3 OPOS DRIVER program, AP3 OPOS DRIVER setup, and making application using AP3 OPOS DRIVER.

Before use AP3 devices, set and configure devices by using AP3 OPOS driver Setup Utility.

Throughout this manual, “OLE for Retail POS” is called “OPOS”.

Throughout this manual, “Unified for Retail POS” is called “UPOS”.

[Further Source]

OLE for Retail POS committee available from <http://monroecs.com/opos.htm>

Read the contents of this manual carefully before using the printer for the first time.

Table of Contents

1. Usage Evironment.....	4
1-1 Features.....	4
1-2 Operation Environment	4
1-3 Accessible Devices	4
2. Installation and Uninstallation	5
2-1 Installation	5
2-2 Uninstallation.....	7
3. Warning.....	8

1. Usage Environment

1-1 Features

- Through these standardized API functions, you can develop POS systems easily.

1-2 Operation Environment

Operating System	Windows XP SP3 (32bit) Windows XP SP1 (64bit) Windows Server 2003 SP1 (32/64bit) Windows Vista (32/64bit) Windows Server 2008 (32/64bit) Windows 7 (32/64bit) Windows 8 (32/64bit) Windows 10 (32/64bit)
Supported Languages	Microsoft Visual Basic Version 6.0 Microsoft Visual C++ Version 6.0 POS for .NET (C#, VB)

1-3 Accessible Devices

1) POSPrinter


Model	Serial	USB	Ethernet
AP3	O	O	O
AP3-3	O	O	O

2. Installation and Uninstallation


The AP3 OPOS driver includes Control Object, Service Object, OPOS Setup Utility, and sample programs.

2-1 Installation

- 1) Run the OPOS Driver installation file.
- 2) "Welcome" dialog is displayed.




- 3) Agree on the software license. At the moment of installation, the user consents to the license policy of AP3.




4) Please select a type of installation. The default installation location is as follows.


- * 32bit OS: "C:\Program Files\OPOS\AP3 OPOS DRIVER\"
- * 64bit OS: "C:\Program Files (x86)\OPOS\AP3 OPOS DRIVER\"



5) The Setup confirmation box will be displayed.




6) Installation of the OPOS driver will proceed.



2-2 Uninstallation

- To remove or modify AP3 OPOS Driver, Select "AP3 OPOS Driver" from "Add / Remove Programs" in Control Panel and remove or modify.



3. Warning

- 1) The AP3 OPOS software package installed supports the devices provided by AP3. Other devices do not guarantee normal operation.
- 2) If installed with other OPOS drivers, it may cause abnormal operation.

Copyright

© Everint Co., Ltd. All rights reserved.

This user manual and all property of the product are protected under copyright law.

It is strictly prohibited to copy, store, and transmit the whole or any part of the manual and any property of the product without the prior written approval of Everint Co., Ltd.

The information contained herein is designed only for use with this Everint product.

Everint is not responsible for any direct or indirect damages, arising from or related to use of this information.

- The Everint logo is the registered trademark of Everint Co., Ltd.
- All other brand or product names are trademarks of their respective companies or organizations.

Everint Co., Ltd. maintains ongoing efforts to enhance and upgrade the functions and quality of all our products.

In the following, product specifications and/or user manual content may be changed without prior notice.

Caution

Some semiconductor devices are easily damaged by static electricity. You should turn the printer “OFF”, before you connect or remove the cables on the rear side, in order to guard the printer against the static electricity. If the printer is damaged by the static electricity, you should turn the printer “OFF”.

Revision history

[illegible]